


# Quick Start Guide

## TP585




**Xiamen Hanin Electronic Technology Co., Ltd.**

TEL: +86-(0)592-5885991


WEB: www.hpert.com

## Appearance


### ■ Front



### ■ Back




### ■ Inside



## Packing List




Printer



Power Cord



USB Cable



Power Adapter



Paper Roll



Quick Start Guide




CD

### ⚠ Notes:


1. The items in the package are dependent on the actual order.
2. The power cord varies by region.

## Paper Loading


1. Pull the cover opening lever to open the front cover.




2. Load the paper roll in the correct direction as shown below. The thermosensitive layer of paper should face to the TPH.



3. Pull out some paper, and close the printer cover.




4. Tear the extra paper.



## Power Supply

1. Make sure the printer is turned off.
2. Connect the power adapter to the printer.
3. Connect the power adapter to the power cord.
4. Plug the other side of the power cord into the socket outlet.



## LED Indicator and Buzzer

LED Indicator		Printer Status	Buzzer Status
Color	Status		
Green	On	On stand-by	---
		Paper sufficient	
Blue	On	Busy	---
Red	On	Paper end	Beep, Beep, Beep
	Flash	Cover open	Beep, Beep-, Beep
		Cutter jam	Beep-, Beep-
		TPH over-temperature	Beep, Beep, Beep

### ⚠Note:

The printer uses a thermistor to detect the temperature of the print head. If the temperature of print head is higher than 65° C, printer will send a warning. If the temperature of print head is higher than 80° C, printer will stop working until the temperature is lower than 60° C.

## Power/Feed Button

- Long press the power button about 3s to turn on/off the printer.
- When the printer is on, short press the feed button once to feed one line of paper.
- When the printer is off, long press the power button about 3s to turn on the printer and hold it until about 6s to print self-test page.
- When the printer is off, open the front cover, long press the power button to turn on the printer and hold it for another 6s to enter into debug mode.

## Bluetooth Setting

Default name: BT Printer-XXXX

Default password: 1234

For Bluetooth setting details, please scan the QR code below:



POS Printer BT Connection Manual

⚠Note: The Bluetooth setting is only valid for the devices with Bluetooth function.