


# Quick Start Guide

## HM-A300S



### Xiamen Hanin Electronic Technology Co.,Ltd

ADD: 5F, 8#, Aide Airport Industrial Park, Huli District, Xiamen, China


TEL: +86-(0)592-5885991

WEB: www.hpert.com


## Packing List



Printer



USB Cable



AC Adapter



Quick Start Guide

### ⚠ Note:

The AC adapter varies by local or region.

The packing materials are actually dependent on the order.

## Appearance and Components


### ■ Front

Paper Roll Perspective Window


LCD

[MODE] Button

[FEED] Button




### ■ Rear



Belt Clip Screw Hole

### ■ Inside



Reset Button

Paper Guide

USB Interface


## Paper Loading

1. Press the cover open button to open the paper cover.




### Note:


1. The paper guide is adjustable, which can hold the paper roll of different specifications.
2. There are two paper guides for the printer. When using 3-inch paper, please disassemble one of them.




2. Load the roll paper in the orientation shown in the figure below.




3. Pull the end of the roll straight toward you. Then press down on both sides of the printer cover to close it firmly.



4. When you close the printer cover, make sure that it is closed on both sides.




5. Use the tear bar to cut the extra paper.




## Battery Charging

Plug in socket with USB charging. When battery pack runs out of power, the battery icon will flash. It powers off automatically when continues printing. If you want to go on, please charge it.



## Menu Settings

1. Press and hold [MODE] button for approx. 2 seconds, and printer is turned on. LCD display is shown as follows.



2. Press both [MODE] button and [FEED] button, the main menu is displayed on the screen, followed by:

Density: Light/Regular/Dark

Paper: Receipt/Label

Feed with closed cover: On/Off

Standby: Setting range n-60, which can be normally set and saved

Shutdown: Setting range n-360, which can be normally set and saved

Self-test Page --- Label Learning --- Quit the Menu

3. Press [MODE] button to change the option.

4. Press [FEED] button to change the category of sub-option; long press [FEED] button to confirm the current setting.

### ⚠ Note:

- ◆Before changing the menu setting, please make sure that the communication with a host device is disconnected.
- ◆When the printer is under the Bluetooth communication with a host device, it cannot enter the Menu Setting mode.

## Bluetooth Setting

Bluetooth Name: HM-A300-xxxx

Bluetooth Code: 1234

## Trouble Shooting

Q: When the printer crashes, how to deal with it?

A: Open the top cover, press the reset button by the needle or toothpick, the printer will be off, and then turn it on again.

