

Label Printer

User Manual

LPQ118



Xiamen Hanin Electronic Technology Co.,Ltd

ADD: 5F, 8#, Aide Airport Industrial Park,
Huli District, Xiamen ,China 361009

Tel.: +86-(0)592-5885993

Fax: +86-(0)592-5885992

Web: www.hpert.com

Contents

MANUAL INFORMATION	1
IMPORTANT SAFETY INSTRUCTIONS.....	2
CHAPTER1 INTRODUCTION.....	5
1.1PACKING LIST.....	5
1.2 APPEARANCE AND COMPONENTS.....	6
1.3 DIMENSION	7
CHAPTER 2 SPECIFICATIONS	8
CHAPTER 3 INSTALLATION & USAGE	10
3.1MEDIA LOADING	10
3.2 POWER CONNECTION	15
3.3PERIPHERALS CONNECTION	16
3.4 DETECTION.....	17
3.5 CONTROL PANEL.....	18
3.6 BASIC OPERATION.....	28
CHAPTER 4 INTERFACE.....	30
4.1USB INTERFACE	30
4.2 OTHER INTERFACES	30
CHAPTER 5 CLEANING.....	32
5.1 CLEANING HEAD.....	32
5.2 CLEANING SENSORS, ROLLER AND/OR PAPER PATH.....	32
CHAPTER 6 LABEL PRINTER UTILITY INSTRUCTIONS.....	33
6.1 INSTALLATION PREPARATION	33
6.2 USAGE.....	33
CHAPTER 7 SEAGULL WINDOWS DRIVER INSTALLATION	40
7.1 INTRODUCTION	40
7.2 INSTALLATION PREPARATION	40
7.3 INSTALLATION	41
CHAPTER 8 BARTENDER® ULTRALITE INSTALLATION	46
8.1 INTRODUCTION	46
8.2 INSTALLATION PREPARATION	46
8.3 INSTALLATION	47

■ Statement

This manual content may be altered without permission, and Xiamen Hanin Electronic Technology Co., Ltd. reserves the rights to make changes without notice in technology, spare parts, hardware and software of the products. If more information is needed about the products, please contact Xiamen Hanin Electronic Technology Co., Ltd. Without any written permission from the company, any section of this manual is prohibited to be copied or transferred in any form.

■ Copyright

This manual is printed in 2016, the copyright belongs to Xiamen Hanin Electronic Technology Co. Ltd.

Printed in China

1.3 Version

■ Warnings



This must be complied with in order to avoid any damage to the human body and the equipment.



This is showing the important information and tips for the printer operation.

Manual Information

This *User Manual* contains basic information for product usage as well as for emergency measures that may be required.

Provides information on utility usage for function selection, operating condition modification etc.

Provides information on Seagull Windows Driver installation.

Provides information on BarTender® UltraLite installation.

※ Following separate manual provide more detailed content on various technological issues and areas.

1.Programming Manual

This manual provides information on label printer commands.

Important Safety Instructions

Before using the present appliance, please carefully read the following safety regulations in order to prevent any hazard or material damage.

1. Safety Warning



Warning: The print head will become very hot during printing, avoid contact with the print head after printing has finished.



Warnings: Do not touch the printer head and connector in case static damage the printer head.

2. Instructions



Warnings: Violating following instructions can cause serious injury or death.

1) Do not plug several products in one multi-outlet.

- This can provoke over-heating and a fire.
- If the plug is wet or dirty, dry or wipe it before usage.
- If the plug does not fit perfectly with the outlet, do not plug in.
- Be sure to use only standardized multi-outlets.

2) You must use only the supplied adapter.

- It is dangerous to use other adapters.

3) Do not pull the cable to unplug.

- This can damage the cable, which is the origin of a fire or a breakdown of the printer.

4) Do not plug in or unplug with your wet hands .

- You can be electrocuted.

5) Do not bend the cable by force or leave it under any heavy object.

- A damaged cable can cause a fire.



Caution: Violating following instructions can cause slight wound or damage the appliance.

- 1) If you observe a strange smoke, odour or noise from the printer, unplug it before taking following measures.
 - Switch off the printer and unplug the set from the mains.
 - After the disappearance of the smoke, call your dealer to repair it.
- 2) Install the printer on the stable surface.
 - If the printer falls down, it can be broken and you can hurt yourself.
- 3) Use only approved accessories and do not try to disassemble, repair or remodel it for yourself.
 - Call your dealer when you need these services.
 - Do not touch the blade of auto cutter.
- 4) Do not let water or other foreign objects drop into the printer.
 - If this happened, switch off and unplug the printer before calling your dealer.
- 5) Do not use the printer when it is out of order. This can cause a fire or an electrocution.
 - Switch off and unplug the printer before calling your dealer.
- 6) Other considerations:
 - Place the printer on a solid and even base so that it cannot fall.
 - Leave enough space around printer for operation and maintenance.
 - Keep all liquids away from the printer.
 - Do not expose the printer to high temperatures, direct sunlight or dust.
 - Ensure the printer is connected to a socket with the correct mains voltage.
 - Switch off the printer POWER supply when it's not in use for a long time.
 - To ensure the printing quality and reliability, suggest use the same quality or recommend paper supplier.
 - Pls. switch off the
POWER supply when connect/disconnect all the ports or it will cause
damage to the printer control circuit.
 - Never carry out maintenance or repair work yourself. Always contact a qualified service technician.
 - Keep this *User Manual* in a place which is easily accessible at all times.

Due to continuous update of product, please regard the real machine as priority, such as accessories, programs etc.

3. Other Precautions

The copyright for this user manual and various other manuals is property of HPRT. Any copying or conversion into electronic form and saving of this material without the express written permission is strictly prohibited. Use of the information contained in this manual is not subject to any patent liability. This manual has been prepared with utmost care and attention to detail but may contain certain errors and/or omissions. HPRT is not legally liable for any damages resulting from the use of the information in this manual. Our company and its affiliates are not legally liable (United States excluded) for any damages, loss, costs, and/or expenses that result from the breakdown, malfunction, and/or misuse of the product due to violation or neglect of the operation and maintenance information and instructions provided by our company, as well as from the unauthorized alteration, repair, and/or modification of the product by the user and/or third party. We are not legally liable for any damages and/or issues resulting from the use of options and/or parts that are not authentic or authorized products.

4. WEEE (Waste Electrical and Electric Equipment)



This mark shown on the product or its literature indicates that the corresponding item should not be discarded at the end of its working life with other household waste. To prevent possible harm to the environment or human health from uncontrolled waste disposal, please separate marked items from other types of waste and recycle them responsibly to promote the sustained reuse of material resources. Household users should contact either the retailer where they purchased this product, or their local government office for details of where and how they can conduct environmentally safe recycling of such items. Commercial users should contact their suppliers and check the terms and conditions of purchase contracts. This product should not be combined with other commercial waste for disposal.



Caution: *This is a Class A product. In a domestic environment this product may cause radio interference in which case the user may be required to take adequate measures.*

Chapter1 Introduction

1.1 Packing List



Notes:

1. Unpack the printer and keep the packing material in case you need to ship the printer in the future.
2. Make sure you own all parts as follows, if not, do contact the seller.


■ Standard Accessories




Printer



Quick Start Guide



CD



Power Cord



Power Adapter




Cables Fastener

■ Optional Accessories



USB Cable




Serial Cable


Note: The type of power cord varies by local or region.

1.2 Appearance and Components


■ Front




■ Rear



■ Insight




■ Install the cables fastener



Note: Views above are for reference only, ports differ by your choice.

1.3 Dimension



Chapter 2 Specifications

(2/1)

Items		Parameter
Printing	Printing Method	Direct Thermal Printing
	Resolution	203dpi(8dots/mm)
	Printing Speed	102mm/s Max.
	Printing Width	108mm Max.
	Printing Length	15mm-300mm
Processor		32 bit RISC CPU
Memory	RAM	2MB
	Flash	2MB
Detection	Sensors	Out of paper detection, Gap detection, Punchhole detection, Black mark detection, TPH temperature detection
Media	Types	Fan-fed or Roll-fed, Die-cut or continuous label
	Width	1"(25.4mm) – 4.64"(117.9mm)
	Thickness	0.003"(76.2um) – 0.007"(177.8um)
	Label Roll Diameter	5"(127mm) Max.
	Core Diameter	1"(25.4mm), 1.5"(38.1mm), 3"(76.2mm)
Programming Language		TSPL
Software	Label Design	Bartender Ultralite
	Seagull Driver	Windows 2000, XP, Vista, 8, 10
Resident Fonts	Bitmap Fonts	8, 12, 16, 24, 32 and OCR A & B 555 90 ° , 180 ° , 270 ° rotatable. 10 times maximum expandable in horizontal and vertical directions.
	TTF Fonts	Monotype CG Triumvirate™ scalable true type font
Code Pages		DOS437, 720, 737, 755, 775, 850, 852, 855, 856, 857, 858, 860, 862, 863, 864, 865, 866, Windows1250, 1251, 1252, 1253, 1254, 1255, 1256, 1257, 1258 ISO8859-1, -2, -3, -4, -5, -6, -8, -9, -15 DBCS 932 (JIS), 936(GBK), 949 (Korean), 950(BIG5)
Barcode Symbolologies	1D	Code 39, Code 93, Code 128UCC, Code 128 subset A, B, C, Codabar, Interleave 2 of 5, EAN-8, EAN-13, EAN-128, UPC-A, UPC-E, EAN and UPC 2 (5) digits add-on, MSI, PLESSEY, POSTNET, RSS-Stacked, GS1 DataBar, Code 11
	2D	PDF417, Maxicode, DataMatrix, QR Code, Aztec

(2/2)


Items		Parameter
Interfaces	Standard	USB
	Optional	USB, RS232C, Ethernet
Control Panel	Display	2.4" TFT LCD
	Button	Touch: Menu, Up, Down, Enter
		Mechanical: Power, Feed
	Status LED	Tri-color
Power Adapter	Power Input	AC 100-240V ~ 50/60Hz
	Power Output	DC 24V 2A
Environment	Operation	41°F -104°F (5°C-40°C), 30% - 85% (non- condensing)
	Storage	-4°F -122°F (-20°C-50°C), 10% - 50% (non- condensing)
Physical Characteristics	Dimension(L*H*W)	244*205*173mm
	Weight	1.5kg(excluding consumables)
Options & Accessories		External label roll holder for 8" OD label rolls
Agency Approvals		CCC, FCC, CE

Chapter 3 Installation & Usage


3.1 Media Loading

3.1.1 Paper Roll Loading


1. Press the cover open lever simultaneously and lift up the printer cover.




2. Hold the center of paper shaft, and slide upwards to pull out.




3. Pull out the paper shield.




4. Insert the media and attention that thermo sensitive layer should face TPH.



5. Put back the paper shield and then shaft, and pull some extra paper out through the paper guides.




6. Close the cover and tear off the excess paper.




3.1.2 Fan-fold Media Loading


1. Place the printer on a even and solid surface.




2. Put the fan-fold media at the rear of printer with the thermo sensitive layer upside, and pass it through the external paper feed slot.



3. Pull the media so that it extends out the front of the printer, adjusted the paper guides based on the paper width. Make sure the guide is just touch, but not restrict, the edges of the media.




4. Close the printer cover.




3.1.3 External Roll Paper Loading

When use big roll paper, please refer to the graph below to assemble the external roll mount and adjust the paper guide to fix the paper. (Please refer to the External Roll Mount Instruction for more detail)



3.2 Power Connection

- 1) Turn off the printer POWER switch.
- 2) Check that the AC adapter voltage matches that of the POWER source and connect the AC adapter to the printer POWER interface.
- 3) Connect the POWER cord to the AC adapter.
- 4) Connect the POWER cord to a POWER source/outlet.




3.3 Peripherals Connection

3.3.1 Interface Cable Connection

Connect the interface cable as shown below.


This printer supports the following communications interface standards.

- RS-232C(Serial) Cable
- USB B-Type Cable
- RJ45 Cable




- 1) Turn off the POWER switch.
- 2) Connect the communication cable to the printer communication port to be used.
 - Connect the RS-232C(Serial) Cable to the serial port.
 - Connect USB B-Type cable to the USB port.
 - Connect RJ45 cable to the RJ45 port.

3.4 Detection



3.5 Control Panel



3.5.1 Control Panel

■ POWER button

① Turn the printer on/off.

When the printer is off, keep pressing POWER button for about 1s, the printer is on and the LED indicator is blue. The printer work normally, the LED indicator is green;

When the printer is on, hold down the POWER button for about 1s, the printer is off and LED indicator disappear.

② Enter the main menu when standing by.

■ FEED button

This button is used to FEED paper manually and at the same time associate to have the self-test.

1) To FEED paper manually under label mode, press this button.

2) Under receipt mode, press this button, the printer will feed a fix or self-set distance

3) For information on the self-test, refer to "Test Printing".

4) While printing, the printer will pause when press FEED button; printer continues to print when press this button again.

LED Indicators





LED Indicators		Printer's Status
Color	Status	
Blue	On	Printer is ready, waiting for printing(Label) status
Green	On	Feed or printing
Red	On	
Yellow	On	Printer is ready, waiting for printing(Continuous media) status
Red	Flash	Out of paper
Blue	Flash	RAM test failed
Pink	On	TPH overheat(When temperature above 80℃ alarm, down to 60℃ alarm canceled)
White	On	Printer is ready, waiting for printing(Black mark media) status

3.5.2 Menu Operation

- Button On LCD screen(when printer is on).

Note: Whether printer has LCD screen or not depends on the printer you bought.




Icon	Name	Description
	Return Button Home Button	① Return to last menu. ② Press this button to cancel settings under setting mode.
	Left Button Up Button	① Choose the option under Menu Mode. ② Choosing items under parameter setting.
	Right Button Down Button	① Choose the option under Menu Mode. ② Choosing items under parameter setting.
	Enter Button	① Confirm current setting/choice.

Note: Under menu mode, no matter which level is, users can press Enter Button cancel the setting and back to last menu.


■ LCD Screen Menu Instruction

Main Menu	Sub-menu	Description	Default
Information	Serial NO.	The serial NO. of printer	
	Printer Name	The model name of printer	
	Firmware	The firmware version	
Printer Param	Language Set	Change the language of system	English
	Factory Reset	Reset to factory	
	Set Menu Psw	Input PSW PSWrange:0000~9999	1001
Interface	RS-232	Set up of Baud Rate, Parity, Data Bits, Stop Bits	
Set Param	Darkness	Adjust the print density Options: (0-4) level	2
	Label Type	Change paper type of printer Options: Receipt, Label, Black Mark	Label
Test	Print Information	Print the printer's information	
	Print Test	Print out the sample to check the darkness of printer; or whether has any problem on TPH	
	Label Learning	Auto Label learning and calibration	



1.Connect printer with power, turn on the power switch, then keep pressing the power button until the printer is on, screen shows as below:





2. Under power on mode, press power button once enter menu mode:




3. Select "1. Information", click enter, click next check next item:











4. Click home button , then click down button , select "2. Printer Param", press enter setting:









● Press enter "2.1 Language Set", press choose language, press confirm:




● Press  back to printer param → press down button  choose "2.2FactoryReset",
press  enter → press   input Psw → press  confirm → press  finish input,
choose "YES", complete factory reset:




Choose "NO", back to last menu.

● Press  back to printer param → press down button  choose "2.3SetMenuPsw",
press  enter → choose "YES" press  → press  input old Psw (default psw is 1001) → input new psw twice → press  complete set menu psw:




Choose "NO" back to last menu.

5.Back to main menu, choose "3.Interface".




● Press set baud rate ● Press set parity




● Press set data bits ● Press set stop bits



6.Back to main menu, choose "4.Set Param".



●Select "4.1Darkenss",adjust darkness.(Range:0、1、2、3、4)




●Select "4.2Label Type", set label type. (Range: receipt、label、black mark)



7.Back to main menu, select"5.Test".



●Select"5.1Print Information", choose "YES" start to print information, choose "NO" back to last menu.



●Select"5.2Print Test", choose "YES" printer start to print test, choose "NO" back to last menu.



●Select "5.3Label Learning" printer start to label learning.




Note: Setting manually is only applicable to printers equipped with LCD screen.

3.6 Basic Operation

3.6.1 Power On/Power Off

Press "-" at the rear turn on the power switch, the printer is on and LED indicator is blue.

Press "O" at the rear turn off the power switch, the printer is off and LED indicator is off.



3.6.2 Feed

1. When the printer is on, press feed button, printer will automatically feed paper to the specified position according to the paper type you use. Press feed button, printer will feed a fixed distance paper under "Continuous Mode"; printer will feed a whole label under "Label Mode".

2. When the printer is printing, press feed button once, current printing job pauses, and the LED indicator is white (tri-color blue, green, red); press feed button again, the printing continues.

3.6.3 Quick Calibration



Note: Users must carry out the calibration under those conditions below:

- First time to use the printer since installation;
- First time to use the printer since sensor cleaning;
- Reuse the printer that has not been used for a long time;
- Change a new type of media;
- Printer cannot recognize the mark;
- Huge change of operating environment;

Calibration method:

1) Carry out calibration manually.

2) Carry out calibration by printer utility. See more information in Label Printer Utility Instructions.

Calibrate Manually:

When printer is ready, hold the FEED button for 3s until the Status Indicator (Blue) flash twice and then release the button, printer start to do the calibration; When printer do calibration under Continuous Media Mode, the calibration is invalid.



Note: After the calibration, users could open the printer cover to pull back the learned paper in avoid of paper wasting.

3.6.4 Print Self-test Page

1. Print Self Test

The self-test checks whether the printer has any problems.

The method of self-test:

1. Make sure the power is connecting and paper is loading properly.
2. Make sure the printer is off and top cover closes properly. .
3. Pressing the paper feed button and power button simultaneously turns the printer on. The printer is ready to receive data as soon as it completes the self-test.

2. Printing by Windows Driver Program

1. Install the Windows Driver program. (Please refer to the **Windows Driver Installation**)
2. Please set the "Interface" as the type you use.
3. Use the Windows Driver Program to print out the "Self-test page".

Chapter 4 Interface

4.1 USB interface





Figure 4-1

PIN No.	Signal name
1	VBUS
2	D-
3	D+
4	GND

4.2 Other Interfaces

■ Serial Interface



PIN NO.	Signal name
1	-
2	TXD
3	RXD
4	-
5	GND
6	RTS
7	-
8	RTS
9	-

■ Ethernet Interface

PIN NO.	Signal name
1	TX+
2	TX-
3	RX+
4	-
5	-
6	RX+
7	-
8	-

Chapter 5 Cleaning

Print quality might be degraded by dust, foreign substance, adhesive substance, or other pollution materials stuck in the printer head or inside the printer.

When dirty, clean the print head as follows:

※ CAUTION

- Make sure to turn the printer off prior to cleaning.
- As the print head gets very hot during printing, if intending to clean the print head, turn the printer off and wait approximately 2~3 minute before commencement.
- When cleaning the print head, take care not to touch the heated portion of the print head.
→ Printer Head is susceptible to damage from static electricity, etc.
- Take care not to allow the print head to become scratched and/or damaged in any way.

5.1 Cleaning Head

- 1) Open the printer cover and then use the cleaning pen to clean the head in the direction from the center of the head to two sides.
- 2) After cleaning the head, do not use the printer until the alcohol used for cleaning evaporates completely (1~2 min) and the printer has completely dried.

※ Perform the cleaning process each time the paper roll is replaced to prevent print quality deterioration.

5.2 Cleaning Sensors, Roller and/or Paper Path

- 1) Open the printer cover and then remove the paper.
- 2) Remove any dust or foreign substance using dry cloth or cotton swab.
- 3) Soak the cloth or cotton swab in alcohol for medical use and use it to remove adhesive foreign substances or other pollution materials.
- 4) After cleaning the parts, do not use the printer until the alcohol evaporates completely (1~2 min) and the printer has completely dried

※ Clean the parts when there is a degradation of performance in printing quality or paper detection degrades.


Chapter 6 Label Printer Utility Instructions

6.1 Installation Preparation

Download HPRTUtilityForLabel application program.eg:Print Utility For Label V2.0.0.1.

6.2 Usage


(1).Open the “HPRTUtilityLabel”. Here is the windows(The screen may vary slightly by different operating systems and models).



(2).Add/Modify/Delete Printer, Connect Test.




- Click “Add Printer” choose the printer and port(take USB for example), click “OK” add successful, check in “Printer List”.



Printer List:

LPQ58	USB	USB
LPQ118	USB	USB


- Click “Modify Printer” choose the printer and port(choose COM1 for example), click “OK” modify successful, check in “Printer List” .



Printer List:


LPQ58	USB	USB
LPQ118	COM	COM1,BAUDRATE_115200

- Click “Delete Printer”, click “OK” delete the printer you chosen, click “Cancel” cancel delete printer.




- Choose the printer you currently use, connect it with computer; Click “Connect Test” to test whether the connection is ok or not.

If connection is OK, the icon below will come out.




If connection fails, normally shows following icon.




Note: Please connect your printer to power first, choose one port (depend on the printer you bought) to connecting to the PC. Connecting method see more information in Power Connection.

When connection fail, please check the connection or whether the port matches.(When USB port is used, it is better to make sure only one printer is connected)


(3).Function.




- Click “Printer Information”, shows printer information.(Differ from your printer)




- Click “Print Test Text”, type the text you need to print→ Set up the printing range(printable width & height)→Click “Print” printer start to print printer test text.



- Click “Print Self Information”, printer print out self-test page.



- Click “Label Auto Learn” printer will carry out the calibration.



- Click “Parameter Setting”.

Parameter setting

COM Port Setting
 Baud Rate: 9600 Parity: NONE
 Stop bits: 1

Language
 International character: U.S.A.
 Codepage: Default

Label paper automatic position when pown on
☒ Disable ☐ Enable

Select small label(Label length < 20mm)
☒ UnSupport ☐ Support

Print type
☒ Thermal ☐ Ribbon

Prprint when error
☒ Disable ☐ Enable

Display "Reprint" when reprint
☐ Disable ☒ Enable

Print density(0:Washiect)
 Print density: 2

Ethernet Setting
 DHCP: Static IP model
 IP address: 192 . 168 . 0 . 35
 Subnet mask: 255 . 255 . 255 . 0
 Default gateway: 192 . 168 . 0 . 1

Other
 Judge paper mode: Label
 Max Mark Length: 200 (0-500)mm
 Min label length: 0 (0-500)mm
 Max label length: 200 (0-500)mm
 Heat Adjust: 0
 Print Speed: 2

After stopping 25 (0-255) mins,enable the anti-adhesive paper function.

Set Close

1) COM Port Setting:

COM Port Setting
 Baud Rate: 9600 Parity: NONE
 Stop bits: 1

2)Language:

Language
 International character: U.S.A.
 Codepage: Default

3)Label paper automatic position when power on:

Label paper automatic position when pown on
☒ Disable ☐ Enable

4)Select small label(Label length < 20mm) :

Select small label(Label length < 20mm)
☒ UnSupport ☐ Support

5)Print when error:

Prprint when error
☒ Disable ☐ Enable

6) Display "Reprint" when reprint:

Display "Reprint" when reprint

☐ Disable ☒ Enable

7) After stopping X mins, enable the anti-adhesive paper function (choose range: 0~255):

After stopping (0-255) mins, enable the anti-adhesive paper function.

8) Print Density (choose range: 0~15, 0 means washiest):

Print Density (0: Washiest)

Print Density:

9) Ethernet Setting:

Ethernet Setting

DHCP:

IP address: . . .

Subnet mask: . . .

Default gateway: . . .

10) Other:

Other

Judge paper mode:

Max Mark Length: (0-500)mm

Min label length: (0-500)mm

Max label length: (0-500)mm

Heat Adjust:

Print Speed:

Judge Paper Mode (Label, Receipt, BlackMark):

Judge Paper Mode:

Codepage:

Heat Adjust:

Max Mark Length (choose range: 0~500mm):

Max Mark Length: (0-500)mm


Min label length (choose range: 0~500mm):

Min label length: (0-500)mm


Max label length (choose range: 0~500mm):

Max label length: (0-500)mm

Heat Adjust:



Print Speed(choose range:2,3,4,):




9)Click "Set" save all the above settings, click "ok" back to the main menu.




Click "Close" back to the main menu and all the settings canceled.

●Click "Restore Factory Settings", click "OK" printer restore factory settings, click "Cancel" cancel restore factory settings.



(4).Click "Quit", finish printer settings.



Chapter 7 Seagull Windows Driver Installation

7.1 Introduction

This chapter provides information on installation according to PC operating system (OS).

This driver support for these following operating systems:

- Microsoft Windows 10 (32 bit/64 bit)
- Microsoft Windows 8 (32 bit/64 bit)
- Microsoft Windows 7 SPI (32 bit/64 bit)
- Microsoft Windows Vista SP2 (32 bit/64 bit)
- Microsoft Windows XP Professional SP3 (32 bit)
- Microsoft Windows Server 2012(64 bit)
- Microsoft Windows Server 2008 R2
- Microsoft Windows Server 2008 SP2(32 bit/64 bit)
- Microsoft Windows Server 2003 R2 SP2(32 bit/64 bit)

7.2 Installation Preparation

Download Seagull Windows Driver application program. Latest version please see our website.

7.3 Installation



Warning: Under different operating system, the screen has slight difference. Please operate it according to the tips. Take Windows XP for example. Recommend to close security software before installation in case of preventing installation.


1. Select one interface to connect your printer to computer.
2. Turn on the printer check if it successfully connected to computer.




3. Double click Seagull Windows Driver.
4. After agree to the EULA, click "Next".



5. Select a directory on the computer to unpack the driver or accept the default location then click "Next".



6. Click "Finish".




7. Select "Install printer drivers" then click "Next".




Note: Connect your printer to computer, can automatically detect and install. (Take USB for example)

8. Select "Install a driver for a Plug and Play printer, click "Next".




9. Enter a name for this printer, click "Next".



10. Click "Finish".



11. Click "Close", the HPRTLQ118 Label printer driver installed successfully.



12. After installation, the icon will be found in "Start" → "Printers and Faxes".



Note:

- 1. If you already installed the driver (No matter what kind of port), when you connect the printer with computer, it will create a USB port automatically.**
- 2. Any problems please use our utility in the CD.**

CHAPTER 8 BARTENDER® ULTRALITE INSTALLATION

8.1 Introduction

This chapter provides information on BarTender® installation according to PC operating systems(OS).

This label design software is available in two versions:32-bit and 64-bit.

8.2 Installation Preparation

Download BarTender® application program.


8.3 Installation




Note : Under different operating system, the screen has slight difference. Please operate it according to the tips. Take Windows 7 for example. (Recommend to close security software before installation in case of preventing installation)

1. Double click application program .


2. Select language, then click "OK".




3. Click "Next".




4. Read and accept the license agreement, then click "Next".




5. Select "Features" and "Installation Location" then click "Next".




6.Click "Installation".




7.If occurs following windows, please choose "Allow this operation", or you may close security software before installation in case of preventing installation.




8. Click "Finish".



9. Select the edition you need (can be changed according to your need while using) ,then click "OK".



10. Click "Close", BarTender® installed successfully.



11. Back to desktop, you may see BarTender® icon, double click it get down to use.

