



Net Configuration Tool Manual

TP80 Series

Rev:1.0

CONTENT

1. Statement.....	3
2. Printer Connecting.....	4
3. Set the IP Address for Printer.....	4
4. Configurate the Net Tool.....	9

1. Statement



This manual content shall not be changed without permission and our company reserve the rights to make changes in it. Please contract our company, if the user needs further information about the products. Without any written permission from our company, any section of this manual is prohibited to be copied or transferred in any form.

This manual describes how to install and configure Network Tools on the HOST. Please read the following instructions carefully and follow the instructions.

This soft applies to the following operating systems:

- Microsoft Windows 10 (32 bit/64 bit)
- Microsoft Windows 8 (32 bit/64 bit)
- Microsoft Windows 7 SPI (32 bit/64 bit)
- Microsoft Windows Vista SP2 (32 bit/64 bit)
- Microsoft Windows Server 2012(64 bit)
- Microsoft Windows Server 2008 R2
- Microsoft Windows Server 2008 SP2(32 bit/64 bit)
- Microsoft Windows Server 2003 R2 SP2(32 bit/64 bit)

- Click the Advanced Settings, then click the Ethernet Setting.



- Ethernet Setting

Note: This setting includes Auto assignment IP and Static IP mode, choosing one of the modes to connect).

Auto assignment IP: this mode automatically assigns the IP address to the printer. After setting, restart the printer.

Ethernet Setting

Board Type:

Board Soft Version:

Ethernet Setting

DHCP:

IP address: . . .


Subnet mask: . . .

Default gateway: . . .


MAC: : : : : :

Static IP mode: Change the printer IP address to make the IP address of the printer is the same segment as the IP address of the host.

Printer IP address: (Such as: 192.168.0.33)



Check IP address of the PC: (Such as: 192.168.1.13)




Change IP address of the printer:


Board Type:	<input type="text" value="Ethernet"/>	
Board Soft Version:	<input type="text" value="V1.00.42"/>	<input type="button" value="Close"/>
Ethernet Setting		
DHCP:	<input type="text" value="Static IP Mode"/>	
IP address:	<input type="text" value="192"/> . <input type="text" value="168"/> . <input type="text" value="1"/> . <input type="text" value="105"/>	
Subnet mask:	<input type="text" value="255"/> . <input type="text" value="255"/> . <input type="text" value="255"/> . <input type="text" value="0"/>	
Default gateway:	<input type="text" value="192"/> . <input type="text" value="168"/> . <input type="text" value="1"/> . <input type="text" value="1"/>	<input type="button" value="Set"/>
MAC:	<input type="text" value="02"/> : <input type="text" value="21"/> : <input type="text" value="00"/> : <input type="text" value="59"/> : <input type="text" value="48"/> : <input type="text" value="88"/>	

4. Configure the Net Tool


- Double click the “HPRTNetWorkUtilityForPOS VX.X.X.X”, then double click .exe software to run it in the host.
- Open the tool, then click the “Scan the printer” to identify printers that are on the same LAN as the current host.



- Check the Status Monitoring to monitor the current status of the printer and set the monitoring interval. For example, the interval is set to 10 seconds, and the tool scans the current state of the printer every 10 seconds.



- If the printer is in an unusual state, the exception message pops up in the lower-right corner of the computer screen.



Note:

Restart Printer: This feature is only available for TP808.

Paper Cut: This feature is only available for models with cutters.