


User Manual

CP2000



Xiamen Hanin Electronic Technology Co.,Ltd

ADD: 5F, 8#, Aide Airport Industrial Park, Huli District, Xiamen, China

TEL: +86-(0)592-5885991

FAX: +86-(0)592-5885992

WEB: www.hpert.com

Installation


01 Installing APP

Scan the following QR code to download APP.




02 Power On

Long press the power switch to turn on the printer.

 In order to ensure safety in transportation, the battery is not fully charged.
You may need to charge it according to the APP prompt after power on.



If you need to charge, please connect the Micro USB cable with the power adapter, and plug it in Charge port of the bottom. After fully charged, the power LED indicator will show blue light constantly.



03 Connection Mode



For iOS system:

- 1) Enter the setting interface of the mobile phone and open Bluetooth function;
- 2) Refresh the Bluetooth device list and select CP2000-XXXX;
- 3) Pair automatically and complete connection.


For Android system:

- 1) Open the APP;
- 2) Before printing photos, open Bluetooth function, enter into the Bluetooth device list and select CP2000-XXXX;
- 3) Pair automatically and complete connection.

Appearance and Components



Micro USB Cable × 1




Integrated Paper Cassette × 1

How to Replace Integrated Paper Cassette

1) Open the cover of the paper cassette.




2) Take out the integrated paper cassette which is used up.




3) Insert the new integrated paper cassette.

 Do not remove the paper cassette or use the photo paper repeatedly.



4) Close the cover of the paper cassette.







Instruction Before Use

1. For power saving, the printer will be standby for 5 min and then off automatically when Bluetooth is not connected.
2. The photo paper will be in and out for 4 times, with three-color printing and coating. Please do not take the paper out before APP showed “print completed”.
3. The photo paper is not reusable. Multiple use will damage the printer mechanism.
4. 9 pcs of photo paper are supplied.

LED Indicator Status

Status Definition: Power Off --- the power is turned off
Standby --- power saving mode
Awaken --- working status

Icon	LED Descriptions	Status	Notes
	Status LED Indicates printer status	Off	Power off
		On	Awaken
		Slow flash	Standby
		Quick flash	Firmware update
	Power LED Indicates the power of battery, charge and discharge status	On	Power is enough when awakening
			Fully charged
		Slow flash	Charging
	Bluetooth LED Indicates Bluetooth connection status	Quick flash	Power is less than 10% when awakening
		Off	Bluetooth is not connected when awakening
		On	Bluetooth is connected when awakening
	Error LED Indicates the error status (once it occurred, the printer cannot print)	Quick flash	Bluetooth is in communication when awakening
		Off	Without abnormality
		On	Paper jam/paper out/cover open in awakening and standby status
		Slow flash	Power is not enough

Attention

1. Recommended operating temperature: 5~35℃, avoid using in the condition of too high or too low temperature.
2. Recommended charging temperature: 5~35℃, avoid charging in the condition of too high or too low temperature.
3. Recommended resolution of the image to use: above 1280*1816.

Specifications

Product Name	Portable Color Printer
Product Model	CP2000
Product Weight	308g (Consumables not included) 345g (Consumables included)
Power Input	5V/1A (Fully charged in 2.5 hours)
Connection Mode	Bluetooth
Technology	Thermal Dye Sublimation
Print Size	54×86mm